



Instructions, care- & safety notices

Pubic Enemy No 1 -
Male electrosex chastity set



Congratulations!

So you've managed to bag yourself a Pubic Enemy No 1. An excellent decision. Now someone's eyes are most certainly going to pop.

Just to make sure that the eyes are the only things that pop, here you'll find step-by-step instructions for attaching, using, removing and looking after your Pubic Enemy and, of course, information about how the electro-stimulation works.

But let's start at the beginning.

What does the Pubic Enemy No 1 do?

The Pubic Enemy is a cock cage: It lets you keep a rebellious tyke pent up under lock and key so that he can't get stiff until he, or she, comes with the key and lets him out. And that can occasionally take a while.




The black conducting surfaces (5), left and right, are for connecting an electro-stimulating device. Then you can treat your prisoner to your heart's content with precisely the intensity of tingles, twitches or pulsations that he deserves.

If you don't want to use this possibility, you can easily remove the conducting surfaces (5) by pressing the black clips (e) on the shaft of the cage inwards and carefully sliding the surfaces out of the Pubic Enemy. If your prisoner gets cheeky later, and the only thing for it is electricity, you can just as easily replace the conducting surfaces in the same way.



The single components

- (1) 1 Cage
- (2) 1 Clasp (with 3 pins (a) and clamp (b))
- (3) 1 Attachment plate with positioning pin (c) and shield holder (d)
- (4) 3 Spacers
- (5) 2 removable conducting surfaces with holding clips (e) and 2mm connectors (f)



Accessories

- (6) 1 metal padlock with 2 keys
- (7) 5 plastic closures
- (8) 10 name shields



(6)



(7)



(8)

How to attach your Pubic Enemy No 1

Right at the start: The Pubic Enemy must be attached in the absence of an erection, first the cage (1) – with a little lubricating gel, the honourable John Willy is enclosed in a jiffy – and then the holding attachment (2-4).

Tip!

If your (soon-to-be) prisoner quickly gets stiff while you are attaching the clasp (2), you can put some water-based lubricant or conductive gel in the fridge beforehand and let it get nice and cool –for example our Bonnie & Glide or The Goldfather for even better conductivity.

When you get that out, he will soon start to behave himself again.

And, so that he doesn't forget who the boss is around here, you can leave him a note (8) in the shield holder (b) to remind him.

To prevent your prisoner from becoming stiff during attachment of the device, start by enclosing the head of the penis in the cage (1) and then insert as much of the penis as possible into the cage.

Next, completely open the clasp (2) and close it behind the scrotum and penis shaft so that the three pins (a) are pointing away from the body and are located on top of the shaft.

Take care that no skin or pubic hairs are caught in the hinges of the clasp.

Slide the attachment plate (3) over the pins (a) of the clasp so that the positioning pin (c) points towards the body – this enables the clamp (b) to be fixed in position. If the positioning pin (c) does not click into position immediately, move the clamp (b) a little backwards and forwards. The whole attachment should lie snugly around the shaft and the scrotum so that the holding device cannot simply fall out of place, but not so tightly that the testicles are squeezed.

GB

When the positioning pin (c) has clicked into position, slide the attachment plate (3) towards the clasp (2) as far as it will go.

Next, slide the cage (1) onto the three pins (a), until it is flush, adjacent to the attachment plate (3).

The penis, now snugly enclosed in the cage (1), should not be squeezed, however. If the cage (1) is too tight, insert as many spacers (4) on the pins (a) between the cage (1) and the attachment plate (3), until the fit is how you want it.

And now, the padlock (6) (or one of the plastic closures (7)) – slide it through the last hole in the central pin (a) and, with an innocent smile, hide the key.

Finally, insert a 2mm plug into each of the connection sockets (f) of the conducting surfaces, (5) right and left, and connect your Pubic Enemy to your electro-stimulator.

It is important that the stimulation current is not switched on until the penis cage has been properly attached.

How to remove your Pubic Enemy No 1

Before removing your Pubic Enemy, please switch off your electro-stimulator and disconnect the plugs. Then unlock the padlock (6) or cut the plastic closure (7) and carefully remove first the cage (1), then the spacers (4) and the attachment plate (3) and finally the clasp (2).

Cleaning & Care

You can clean all the components of your Pubic Enemy No 1 with water and a mild soap. At regular intervals, you should also use a skin-friendly disinfectant (Please observe the respective instructions for use). For a thorough cleaning of the conducting surfaces (5), it is also possible to remove them: to do this, please press gently inwards on the holding clips (e) on the shaft of the cage with your fingers and carefully remove the surfaces from the cage. Before re-assembling or re-using your Pubic Enemy, please make sure that it is completely dry.

The thing with the stimulation current

E-Stim, i.e. electrical stimulation, has been gaining ever more popularity in recent years, and no wonder. In the intimate areas there are lots of nerves – far more than in other parts.

With a properly regulated device for electrical stimulation and the appropriate toys, you can stimulate every single one of these nerves to a state of ecstasy.

This stimulation is perfectly safe if it is carried out with due care and attention and high-quality products.



⚠ There are a couple of things that you absolutely must be careful of:

- Persons with electronic or metal implants (e.g. heart pacemakers) must not use stimulation current without previously consulting a medical doctor. The same applies to persons with heart trouble or cardiac arrhythmia.
- Stimulation must never be carried out in a way in which current is conducted through the brain or the heart. Never stimulate the larynxes or the area of the throat. Muscle cramps in this area can lead to suffocation.
- Electrical stimulators must not be used in the vicinity of explosive or inflammable materials.
- Stimulating current may only be used on healthy skin.
- Keep out of reach of children.

More information on E-Stim can be found under www.mystim.com.

Any questions?

Just contact us.
We'll take care of it.
hello@mystim.com

Videos showing the use and care of our toys:
www.mystim.com/care_instructions.html



**Hersteller / manufacturer / fabricant / fabricante /
fabrikant / fabbricante / производитель**

Mystim GmbH
Königsberger Str. 26
63776 Mömbris
GERMANY

Oktober 2013